



StageScreen Projection Screen by Draper—Assembly Map



For use with these part numbers:

383279 383488 383312 383554



⚠ Before you start:

- Spread the tarp (included).
- Lay the viewing surface out face down on the tarp.
- Assemble the frame on top of the screen surface.
- Frame sections should be arranged so that:
 - Viewing surface attachment posts are on the outside of the frame
 - Guide pins should point clockwise
 - Rivcuts should face upward



⚠ Caution:
Beware of pinch points.

DRAPER

411 S. Pearl St., Spiceland, IN 47385 USA ■ 765-987-7999
www.draperinc.com ■ fax 765-987-7142
Copyright © 2012 Draper Inc. Form StageScreen_144x192_Assy Printed in U.S.A.