## StageScreen Projection Screen by Draper—Assembly Map

Stiffener Stiffener Stiffener Stiffener 6'(183cm) 2'(61cm) 5' (152cm) Red dots above indicate recommended approximate attachment points for flying or for wall bracket locations if wall-mounted. 94½" x 168" (240 x 427 cm) Image Area—16:9 HDTV Format 31/2′ (107cm) 3½′ (107cm) For use with these part numbers: **⚠** Before you start: Spread the tarp (included). 383288 383497 383321 383563 • Lay the viewing surface out face down on the tarp. • Assemble the frame on top of the screen surface. • Frame sections should be arranged so that: >> Viewing surface attachment posts are on the outside of the frame ➡ Guide pins should point clockwise All Pins should > Rivcups should face upward point clockwise. Rivcups should 3½′ (107cm)



411 S. Pearl St., Spiceland, IN 47385 USA **■** 765-987-7999 www.draperinc.com ■ fax 765-987-7142

Copyright © 2012 Draper Inc. Form StageScreen 94-5x168 Assy Printed in U.S.A.



Beware of pinch points.

2'(61cm)

5' (152cm)

6' (183cm)

Stiffener

Stiffener

**Stiffener** 

Stiffener