

StageScreen Projection Screen by Draper—Assembly Map



Stiffener

Stiffener

Stiffener

Stiffener

5' (152cm)

5' (152cm)


5' (152cm)

Red dots above indicate recommended approximate attachment points for flying or for wall bracket locations if wall-mounted.

108" x 192" (274 x 488 cm) Image Area—16:9 HDTV Format

For use with these part numbers:

383289 383498 383322 383564



⚠ Before you start:

- Spread the tarp (included).
- Lay the viewing surface out face down on the tarp.
- Assemble the frame on top of the screen surface.
- Frame sections should be arranged so that:
 - Viewing surface attachment posts are on the outside of the frame
 - Guide pins should point clockwise
 - Rivets should face upward



⚠ Caution:
Beware of
pinch points.

4' (122cm)

4' (122cm)

4' (122cm)

4' (122cm)

DRAPER®

411 S. Pearl St., Spiceland, IN 47385 USA ■ 765-987-7999
www.draperinc.com ■ fax 765-987-7142
Copyright © 2012 Draper Inc. Form StageScreen_108x192_Assy Printed in U.S.A.

5' (152cm)

5' (152cm)

5' (152cm)

Stiffener

Stiffener

Stiffener

Stiffener