


# StageScreen Projection Screen by Draper—Assembly Map




Red dots above indicate recommended approximate attachment points for flying or for wall bracket locations if wall-mounted.

## 270" x 480" (686 x 1219 cm) Image Area—16:9 HDTV Format

For use with these part numbers:

383294 383503 383327 383569



- ⚠ Before you start:**
- Spread the tarp (included).
  - Lay the viewing surface out face down on the tarp.
  - Assemble the frame on top of the screen surface.
  - Frame sections should be arranged so that:
    - ▶ Viewing surface attachment posts are on the outside of the frame
    - ▶ Guide pins should point clockwise
    - ▶ Rivcuts should face upward



**⚠ Caution:**  
Beware of  
pinch points.

# DRAPER®

411 S. Pearl St., Spiceland, IN 47385 USA ■ 765-987-7999  
www.draperinc.com ■ fax 765-987-7142  
Copyright © 2012 Draper Inc. Form StageScreen\_270x480\_Assy Printed in U.S.A.