StageScreen Projection Screen by Draper—Assembly Map

Stiffener Stiffener Stiffener

5'(152cm)

5'(152cm)


5' (152cm)

Red dots above indicate recommended approximate attachment points for flying or for wall bracket locations if wall-mounted.

120" x 192" (305 x 488 cm) Image Area—16:10 Format

For use with these part numbers:

383299 383508 383332 383574



411 S. Pearl St., Spiceland, IN 47385 USA ■ 765-987-7999 www.draperinc.com ■ fax 765-987-7142

Copyright © 2012 Draper Inc. Form StageScreen_120x192_Assy Printed in U.S.A.

⚠ Before you start:

- Spread the tarp (included).
- Lay the viewing surface out face down on the tarp.
- Assemble the frame on top of the screen surface.
- Frame sections should be arranged so that:
 - ➤ Viewing surface attachment posts are on the outside of the frame
 - ➡ Guide pins should point clockwise
 - ➡ Rivcups should face upward



∴ Caution: Beware of pinch points.

5'(152cm)

5' (152cm)

5' (152cm)

Stiffener

3′ (91cm)

6' (183cm)

Stiffener

Stiffener

Stiffener

6′ (183cm)